40 Watt Reverse Electricity Converter

273-1411 OWNER'S MANUAL — Please read before using this equipment.

Thank you for purchasing a RadioShack 40 Watt Reverse Electricity Converter. Your converter is designed for use with 220/240 volt motorized electronic or heating appliances rated up to 40 watts. Your converter is perfect for use with electric razors, curling irons, calculators, radios, CD players, cassette recorders, flash guns, oral hygiene devices, and battery chargers.

Note: Your converter only converts voltage, not frequency. Some devices might run slightly faster than originally designed.

1. Turn off power to the receptacle at the fuse box or circuit breaker.
2. Remove the receptacle cover plate's screw. Do not remove the receptacle cover plate.
3. Plug the converter into the lowest outlet. Place the screw through the converter screw ring. Reattach the receptacle cover plate.
4. Turn on power to the receptacle.
5. Insert your appliance's plug into the converter.

Cautions:

- To prevent electric shock or fire, connect the reverse connector directly to a grounding receptacle.
- To reduce the risk of electric shock, disconnect power to the receptacle before installing or removing the converter. When you remove the receptacle cover screw, the cover may fall across plug pins or the receptacle may be displaced.
- Use the converter only with 110/120 volt AC duplex receptacles which have a center screw. Secure the converter with the receptacle cover screw.
- Do not place or store the converter where it can fall or be pulled into a tub or sink.
- Do not place or drop the converter into water or other liquids.

RadioShack®
www.radioshack.com℠

© 2001 RadioShack Corporation. All Rights Reserved.
RadioShack and RadioShack.com are trademarks
used by RadioShack Corporation.

OVERHEAT PROTECTION

Your converter is equipped with an internal shut off and reset system. Should it ever become overworked, it automatically turns itself off. If this occurs, remove the converter from the outlet and allow a short period for it to cool down and reset itself. At times there may be a low humming sound in the converter, this is normal.

Warnings:

To reduce the risk of burns, electrocution, fire, or injury:

- Use this converter only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Do not plug the converter into an extension cord.
- Never use this converter if it has a damaged plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the converter to your local Radio Shack store for assistance.
- Never obstruct air circulation to the converter.
- Never drop or insert any object into the converter's openings or holes.
- Do not use the converter outdoors.
- For use with 110/120 volt AC electricity.
- The converter will not work with direct current (DC).

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

12/99

RadioShack Corporation
Fort Worth, Texas 76102

273-1411
11/01
Printed in the USA